


User Manual
Battery Energy Storage System
Soluna Venus 16K Pack LV
A.0



About this Specification

This manual provides comprehensive instructions for installing the Soluna Venus 16K Pack LV. It is imperative to thoroughly read this manual before attempting to install the product and to follow the instructions diligently throughout the installation process.

If you have any doubts about the requirements, recommendations, or safety procedures described in this manual, please contact Soluna immediately for advice and clarification.

The information contained in this manual is accurate at the time of publication. However, due to ongoing updates to product design and technical specifications, our company reserves the right to make changes at any time without prior notice. Additionally, the illustrations included in this manual are intended to aid in explaining system configuration concepts and installation instructions. The items depicted in the illustrations may differ from the actual items at the installation site.

SOLUNA (SHANGHAI) CO.,LTD reserves the copyright of this document.

1. Introduction.....	05
2. Features.....	06
2.1 Features.....	06
2.2 Application.....	06
3. Safety Precautions.....	07
3.1 Warning Sign.....	07
3.2 Safety Instructions.....	08
3.2.1 Ris ks of Explosion.....	08
3.2.2 Ris ks of fire	08
3.2.3 Ris ks of electric shock.....	08
3.2.4 Ris ks of damage to the battery pack.....	08
3.3 Bat tery handling guide.....	09
3.4 Response to emergency situations.....	09
3.4.1 Leaking bat teries	09
3.4.2 Inhalation.....	09
3.4.3 E ye contact.....	09
3.4.4 Skin contact.....	09
3.4.5 Ingestion.....	10
3.4.6 Fire.....	10
3.4.7 Wet batteries.....	10
3.4.8 Damaged bat teries	11
3.5 Qualified installers.....	11
4. Appearance.....	12
5. Technical parameters.....	14
6. Connection Port	16
7 COM Communication Interface Definition	18
8 LED Lights Definition.....	19
9 Installation.....	20
9.1 Packing Lists.....	20
9.2 Installation Materials.....	21
9.3 Installation Location.....	21
9.4 Installation Tools Requirements	22
9.5 Wiring Specification.....	23

9.6 Installation Method	24
9.7 Installation Method	25
9.8 Installation Method	26
9.9 CAN communication connection	27
10. Electrical connection.....	28
11. How to operate Soluna Venus 16K Pack L V.....	30
12. Trouble shooting guideline.....	31
13. Depth of Discharge (DOD) Setting for inverter.....	34
14. Contact us.....	35

The Soluna Venus 16K Pack LV is an advanced LFP lithium battery product designed to meet the highest standards of performance and safety. Equipped with a sophisticated Battery Management System (BMS), this low-voltage battery module features CAN/RS485 communication for seamless integration and monitoring. It includes comprehensive protections against under-voltage, over-voltage, over-current, over-temperature, and under-temperature, ensuring optimal performance and safety under various conditions.

With its high energy density, long lifespan, and robust reliability, the Soluna Venus 16K Pack LV stands out as a green environmental product you can trust. Its innovative design not only enhances efficiency but also contributes to sustainability, making it an ideal choice for Backup Power, Micro-grid Solutions, and Small Industrial & Commercial Energy Storage Systems.

2.1 Features













- **Excellent Safety Performance**
Ensures the highest level of safety under various conditions.
- **Long Cycle Life**
Designed for extended usage without significant performance degradation.
- **Support CAN/RS485**
Allows seamless integration and communication with other systems.
- **Parallel Interconnection**
Enables the connection of several systems in parallel for increased capacity.
- **Expandable Battery Units**
Provides flexibility to scale the system as needed.
- **Backup Power**
Reliable power supply during outages.
- **Micro-grid**
Supports independent and sustainable energy systems.
- **Home Energy Storage System**
Efficiently stores energy for residential use.

2.2 Application

- Back-up power
- Micro-grid
- Home Energy Storage system

3.1 Warning Signs

Warning signs are essential indicators designed to alert you to conditions that could result in severe injury or significant damage to the device. They serve as critical reminders to exercise caution and take necessary precautions to prevent hazardous situations. The table below outlines the warning signs used in this manual and their meanings:

Sign	Description
	High Voltage Warning: This battery pack operates at high voltage, which can cause severe injury due to electric shock.
	Correct Polarity: Ensure the battery polarity is correctly connected.
	Fire Safety: Keep the battery pack away from open flames or ignition sources.
	Child Safety: Store the battery pack out of reach of children.
	Installation Manual: Thoroughly read the manual before installing and operating the battery pack.
	Heavy Weight Warning: The battery pack is heavy, and improper handling may result in severe injury. Utilize proper lifting techniques.
	Electrolyte Leakage: The battery pack may leak corrosive electrolyte. Handle with care and adhere to appropriate safety procedures.
	Explosion Risk: The battery pack may explode under certain conditions.
	Disposal Instructions: Do not dispose of the battery pack with household waste at the end of its working life. Follow local regulations for disposal.
	Compliance Requirement: Failure to follow the provided requirements and guidelines may lead to physical injury or damage to the device.
	Do not short circuit.
	Grounding conductor This symbol indicates the position for connecting a grounding conductor.

3.2 Safety Instructions

For safety reasons, it is crucial that installers thoroughly familiarize themselves with the contents of this manual and all associated warnings prior to commencing the installation.



General Safety Precautions

Failure to adhere to the precautions outlined in this section can result in serious injury or property damage. Please observe the following safety guidelines:

3.2.1 Risks of Explosion

- Avoid subjecting the battery pack to strong impacts.
- Do not crush or puncture the battery pack.
- Never dispose of the battery pack in a fire.

3.2.2 Risks of Fire

- Do not expose the battery pack to temperatures exceeding 60°C.
- Keep the battery pack away from heat sources, such as fireplaces.
- Avoid exposing the battery pack to direct sunlight.
- Ensure the battery connectors do not come into contact with conductive objects like wires.

3.2.3 Risks of Electric Shock

- Refrain from disassembling the battery pack.
- Do not touch the battery pack with wet hands.
- Keep the battery pack away from moisture or liquids
- Ensure the battery pack is kept away from children and animals.

3.2.4 Risks of Damage to the Battery Pack

- Prevent the battery pack from coming into contact with any liquids.

3.3 Battery Handling Guide

- Use the battery pack strictly as directed in the manual.
- Do not use the battery pack if it appears defective, cracked, broken, or fails to operate correctly.
- Do not attempt to open, disassemble, repair, tamper with, or modify the battery pack as it is not user serviceable.
- Handle the battery pack with care during transportation to avoid damage.
- Avoid impacting, pulling, dragging, or stepping on the battery pack.

3.4 Response to Emergency Situations

The Soluna Venus 16K Pack LV consists of multiple batteries designed to prevent hazards resulting from failures. However, Soluna cannot guarantee absolute safety. Please familiarize yourself with the following emergency procedure.

3.4.1 Leaking Batteries

If the battery pack leaks electrolyte, avoid contact with the leaking liquid or gas. Electrolyte is corrosive and contact may cause skin irritation and chemical burns. If exposed to the leaked substance, follow these steps:

3.4.2 Inhalation

- Evacuate the contaminated area immediately.
- Seek medical attention without delay.

3.4.3 Eye Contact

- Rinse eyes with flowing water for at least 15 minutes.
- Seek medical attention immediately.

3.4.4 Skin Contact

- Wash the affected area thoroughly with soap and water.
- Seek medical attention immediately.

3.4.5 Ingestion

- Induce vomiting.
- Seek medical attention immediately.

3.4.6 Fire Response Procedures

In the event of a fire, always have an ABC or carbon dioxide extinguisher on hand.



The battery pack may ignite if heated above 150 °C. If a fire occurs where the battery pack is installed, follow these steps:

- **Extinguish Early**

Attempt to extinguish the fire before the battery pack ignites.

- **Safe Relocation**

If extinguishing is not possible but time allows, move the battery pack to a safe area before it catches fire.

- **Evacuate**

If the battery pack has already caught fire, do not attempt to extinguish it. Evacuate the area immediately.



Caution: If the battery catches fire, it will emit noxious and poisonous gases. Do not approach the fire.

3.4.7 Wet Batteries

If the battery pack becomes wet or submerged in water, do not attempt to access it. Contact Soluna or your distributor for technical assistance immediately.

3.4.8 Damaged Batteries

Damaged batteries are hazardous and must be handled with extreme caution. They are unfit for use and may pose a danger to people or property.

If the battery pack appears damaged, pack it in its original container and return it to Soluna or your distributor.



Leakage and Flammability: Damaged batteries may leak electrolyte or produce flammable gas. If you suspect such damage, contact Soluna for advice and information immediately.

3.5 Qualified Installers

This manual, along with the tasks and procedures described herein, is intended for use by skilled professionals only. A skilled professional is defined as a trained and qualified electrician or installer who possesses all of the following skills and experience:

- **Functional Knowledge**

Understanding of the principles and operation of on-grid systems.

- **Risk Awareness**

Awareness of the dangers and risks associated with installing and using electrical devices and the acceptable methods for mitigating these risks.

- **Installation Proficiency**

Expertise in the installation of electrical devices.

- **Adherence to Guidelines**


Knowledge of and compliance with this manual, including all safety precautions and best practices.

- **Battery Maintenance**


Only authorized personnel should perform maintenance. Turn off the battery before maintenance. Periodically check voltage, SOC, and cables for damage or wear. Perform balancing maintenance (fully charge) every three months.

- **Installation Environment Requirements**

Avoid flammable, explosive, or corrosive materials. Keep out of children's reach and avoid high temperatures. Ensure proper ventilation and avoid electromagnetic interference. Install in a sheltered, well-ventilated area, within the appropriate temperature and humidity range, and below 2000 meters altitude.



Width	545	mm
Depth	220	mm
Height	850	mm
Weight	127	kg



Number	Name	Description
1	Logo	Soluna brand
2	Cable connection interface	A port or set of ports designed for connecting cables, such as USB, HDMI, or Ethernet, to establish connections with other devices or networks.
3	Power ON/OFF switch	A physical toggle or push-button control to turn the device on or off. It may include additional features, like an LED indicator to show the device's power status.
4	Battery capacity & Status indicator light	A display or light system that shows the battery's capacity (measured in milliamp hours, mAh, or watt-hours, Wh) and status (e.g., charging, full, or low battery), often using colors or blinking patterns.

5 Technical parameters

Physical Characteristics	
Width	545 mm
Depth	220 mm
Height	850 mm
Weight	127 kg
Electrical Characteristics	
Battery type	LFP
Total Energy Capacity	16.07k Wh
Usable Energy Capacity	14.46kW h
Battery Capacity (Nominal)	314 Ah
Nominal Voltage	51.2V
Usable Voltage Range	48~57.3 V
Charge Current (Recommended)	150A
Discharge Current (Recommended)	150A
Max. Continuous Charge Current	160A
Max. Continuous Discharge Current	220A
Recommended Depth of Discharge	80%
Max. Depth of Discharge	90%
Internal resistance	≤20mΩ
Cycle life @ 25°C(under standard charge and discharge Conditions)	≥8000
DC Disconnect	Contactora / Fuse
Warranty	


5 Technical parameters

Please refer to Soluna WARRANTY CONDITIONS	
BMS	
Power consumption	<3W (work), <10 0mW (sleep)
Monitoring parameters	System Voltage, System Current Cell Voltage, Cell Temperature SOC, SOH
Communication	CAN / RS485
Protection	Over Voltage, Under Voltage Over Current, Over Temperature Under Temperature
System Configuration	
Module parallel	1~ 30 Parallel
Operating Conditions	
Installation Location	Indoor / Outdoor
Operating Temperature	Charge:0-50°C,Discharge:-10-50°C ^①
Operating Temperature (Recommended)	15~30°C
Storage Temperature	15~50 °C
Humidity	5%~95%
Altitude	Max. 2,000 m
Cooling Strategy	Natural Convection
Reliability & Certification	
Certificates	CE RoHS, IEC 62619
Transportation	UN38.3
Ingress Rating	IP65

①: The default version of the battery is the non-heating version. If a heating version is required, please communicate in advance before placing an order.

6 Connection Port

The connection ports of the Soluna Venus 16K Pack LV become visible once the cover plate is opened. Please refer to the attached pictures for further details.




Number	Name	Description
1	Cover plate	This is a protective panel that safeguards the internal components of a device, ensuring that delicate parts are shielded from damage. It can usually be removed or opened to allow access for maintenance, inspection or connections to various ports and terminals.
2	Battery+	This is the positive terminal of the battery pack. It is used to connect the positive side of the electrical load or inverter.

3	Battery-	This is the negative terminal of the battery pack. It is used to connect the negative side of the electrical load or inverter.
4	FUSE	A safety device designed to protect the electrical circuit by interrupting power flow in case of excessive current.
5	CAN1 port	For internal communication (BMS) This port enables communication within the Battery Management System (BMS), ensuring efficient battery monitoring and management.
6	CAN2 port	For external communication (inverter) This port allows the battery pack to communicate with the inverter, facilitating power conversion and system integration.
7	CAN1 dial switch	A manual switch associated with the CAN1 port, used for configuring or adjusting communication settings.
8	CAN2 dial switch	A manual switch associated with the CAN2 port, allowing users to modify or configure communication settings.
9	Remote port	A port designed for connecting a remote control or other external devices, enabling extended operation or monitoring.

7 COM Communication Interface Definition

Once the cover plate of the Soluna Venus 16K Pack LV is opened, users can view the connection ports of the battery. Please refer to the images below for detailed visuals.



CAN1

1	2	3	4	5	6	7	8
RS485A (WiFi)	RS485B (WiFi)	5V	CAN-H	CAN-L	GND	—	—

CAN2

1	2	3	4	5	6	7	8
—	—	—	CAN-H	CAN-L	—	RS485A	RS485B

Remark:

- 1) CAN1 is used for BMS parameters monitoring
- 2) CAN2 is used for Inverter communication

8 LED Lights Definition




Figure 2.5 LED lights definition

Number	Name	Description
1	25% capacity light	Green light
2	50% capacity light	Green light
3	75% capacity light	Green light
4	100% capacity light	Green light
5	Status indicator light	Yellow light

Remark(Indicator Running State Information)

- **Push Button Switch**

A white light will turn on when the button is pressed.

- **Status Indicator Light**

Normal Operation: The light stays continuously on when there is no alarm.

Battery alarm: If the Soluna Venus 16K Pack LV has an alarm, the orange status light flashes at a frequency of 1 S/time.











Communication failure: If the Soluna Venus 16K Pack LV cannot communicate with the inverter, the orange status light flashes for 3 seconds and turns off for 2 seconds.


Turn on heating: When the Soluna Venus 16K Pack LV turns on the low-temperature heating function, the orange status light is always on, and the green indicator light scrolls from bottom to top in the form of a running light

Start Upgrade: When the Soluna Venus 16K Pack LV is upgrading its software, all indicators flash simultaneously.

9.1 Packing List

The following table lists the numbers of each item included. If anything is damaged or missing, contact SOLUNA or your distributor.

Item	Name	Description	Qty (pcs)	Photo
1	Soluna Venus 16K Pack LV	The battery	1	
2	Wall fixed support frame	Sturdy wall-mounted frame for structural equipment support.	1	
3	Foot hanging ear-left	Left-side mounting bracket/ear for secure equipment attachment to support frame	1	
4	Foot hanging ear-right	A right-side bracket or ear for attaching equipment to the support frame.	1	
5	Bottom corner support frame-left	A left-side corner support frame for stabilizing and reinforcing the equipment's bottom structure.	2	
6	Expansion screws	6mm x 1 6mm metric screws for assembling or securing equipment parts.	11	
7	Wrench	Tool for tightening or loosening nuts, bolts, or screws.	1	
8	Screws-M6*1 6	Screws for anchoring into walls or surfaces to securely mount the support frame or equipment.	7	
9	Positioning cardboard	Cardboard template for marking drilling points and mounting locations during installation.	1	
10	Handle	Used for easy gripping and convenient operation of the device.	1	

Item	Name	Description	Qty (pcs)	Photo
10	Communication cable(2m)	2-meter cable for communication and data transmission between equipment and devices.	2	

9.2 Installation Materials

These installation materials shall be prepared by installers.

- Charging cables
- Communication cable.

9.3 Installation Location

We recommend that Soluna Venus 16K Pack LV is used in Soluna Home energy storage systems, if not, please Make sure that the installation location meets the following conditions:

- The building is designed to withstand earthquakes.
- The location is far away from the sea, to avoid salt water and humidity.
- The floor is flat and level.
- There are no flammable or explosive materials nearby.
- The ambient temperature is between 15 and 30°C.
- The temperature and humidity stays at a constant level.
- There is minimal dust and dirt in the area.
- There are no corrosive gases present, including ammonia and acid vapor.
- Do not place the battery system in direct sun light. it is suggested to build sunshade equipment In cold area the heating system is required.



If the ambient temperature is outside the operating range, the battery pack stops operating to protect itself. The optimal temperature range for the battery pack to operate is 15°C to 30°C. Frequent exposure to harsh temperatures may deteriorate the performance and lifetime of the battery pack.

9.4 Installation Tools Requirements

The following tools are required to install the battery pack:

Remark:

Use properly insulated tools to prevent accidental electric shock or short circuits.

Item	Photo	Name
1		Phillips-screwdriver bit
2		Wire cutters
3		Wire stripper
4		Tape measure
5		Pistol drill
6		Spirit level
7		Electrical insulating tape
8		Multimeter
9		Marker pen

When handling the battery pack, it is essential to wear the appropriate safety gear to protect against potential hazards, installers must adhere to the relevant requirements of international standards, such as IEC 60364, or comply with domestic legislation.

1		Safety goggles
2		Safety shoes
3		Insulated gloves

9.5 Wiring Specification

In order to standardize the wiring specification of Soluna Venus 16K Pack LV, the following requirements are required for connecting wires of Soluna Venus 16K Pack LV.


Battery Wire	Communication Cable
It is recommended to use 70 mm ² (2/0 AWG) of conductor with double insulation.	It is recommended to use standard communication cable with shielding function.

9.6 Installation Method

Wall-Mounted Installation


Step 1: Mark Mounting Hole Locations

Put the positioning cardboard against the wall to mark the location of the mounting holes.




Step 2: Drill Holes

Use a percussion drill to make holes at the marked positions, and the size of the hole is 10mm.




Step 3: Install Wall Bracket

Use 10 expansion screws to install the wall bracket and the wall mounting bracket to the wall.




Step 4: Mount the Battery

Put the battery on the wall bracket. Install the product on the bracket with 6 M5 screws.



Step 5: Connect Wiring

After fixing the product, install the wire harness.




9.7 Installation Method

Rack-mounted installation


Step 1:

Fix the left and right lugs to the battery pack with a torque of $7N \cdot M \pm 10\%$




Step 2:

Fix the battery pack to the frame with M6 three-in-one screws as shown below, with a torque of $7N \cdot M \pm 10\%$




Step 3:

After fixing the product, install the wire harness



Step 4:

After connecting the cables properly, fix the outlet cover plate to the outlet cavity position




* Please note that the bracket is not included in the product package

9.8 Installation Method

Floor mounting


Step 1:

Fix the bracket on the product with 4 PCS M6 screws.




Step 2:

Use a percussion drill to make holes at the marked positions, and the size of the hole is 10mm.




Step 3:

Use 3 expansion screws to install the wall bracket and the wall mounting bracket to the wall.




Step 4:

Put the battery on the wall bracket, Install the product on the wall support with two M6 screws, and secure the foot support with four M6 expansion screws.



Step 5:


After fixing the product, install the wire harness.




9.9 CAN communication connection

Please find the following drawing for details.


1x Battery




2x Battery



3x Battery



(4-12)x Battery




Please follow the diagram to adjust the switches, ensuring proper configuration

- CAN 1 Connection Link
- CAN 2 Connection Link

Standalone


- Communication cable
- Battery positive pole
- Battery negative pole



- 1) The "2" on the DIP switch of the first battery CAN1 and CAN2 port should be turned to the "ON" position.

Multiple Clusters

- Communication cable
- Battery positive pole
- Battery negative pole



- 1) The DIP switch of port CAN1 of the first parallel box should be set to the "on" position.
- 2) The DIP switches for ports CAN1 and CAN2 of the last parallel box should be set to the "on" position

11 How to operate Venus 16K Pack LV


There are two ways to start the Soluna Venus 16K Pack LV. Below are the details for each mode:

Starting Mode 1 (Factory Default)

- Connect Pin 2 and Pin 3 on the 3-pin jack plug.
- Press the metal button switch.
- The Soluna Venus 16K Pack LV will start operating within 25 seconds.
- If no communication is established within 5 minutes, the system will stop outputting power.

Starting Mode 2

- Install a switch between Pin 1 and Pin 2 on the 3-pin jack plug.
- Turn the switch on.
- The Soluna Venus 16K Pack LV will start operating within 25 seconds.
- If no communication is established within 5 minutes, the system will stop outputting power.



Number	Name	Description
1	3pin jack plug	<p>A 3-pin jack plug is a type of electrical connector commonly used for audio and power applications. It typically consists of three pins or terminals:</p> <p>Live Pin: Carries the electrical current or signal.</p> <p>Neutral Pin: Completes the circuit by returning the current.</p> <p>Earth Pin: Provides a safety pathway for electrical faults, preventing shocks.</p>

12 Trouble shooting guideline

Please find the following table for details

Phenomenon	LED Alarm	Possible root cause	How to target the root cause	Solution
No communication between battery and inverter	LED is off	1) Compatible inverter firmware is not the latest version.	Please check the inverter APP or LCD/LED for firmware reversion.	Update inverter's firmware.
		2) The battery firmware is incompatible with the inverter manufacturer.	Please use canbus tool box or Soluna smart energy cloud to check firmware reversion.	Update battery's firmware.
		3) Installer didn't choose Soluna battery correctly on inverter side.	Please check if the selection of battery is correct or not.	Re-select Soluna battery on inverter.
		4) Communication cable is loose or not correct.	Please check the communication cable status.	Re-plug or change the communication cable.
		5) Terminal resistor dial incorrectly.	Check the position of resistor dial.	Redial the terminal resistor.
		6) Inverter hardware fault.	Please change another inverter to try.	Redial the terminal resistor.
		7) Battery hardware fault.	Please change another battery to try.	Contact Soluna for additional support and next steps.
Battery can't be charged or discharged	N/A	1) Inverter setting incorrect such as disable the charging or discharging, and time setting, etc.	Check the inverter setting.	Reset the inverter setting.
		2) Inverter can't read Soluna battery type correctly.	Please check the battery type of product and product name shown in inverter side.	Contact with Inverter manufacturer or Soluna for additional support and next steps.
		3) Inverter hardware fault.	Please change another inverter to try.	Contact with Inverter manufacturer.
		4) Battery hardware fault.	Please change another battery to try.	Contact with Soluna for additional support and next steps.

12 Trouble shooting guideline

Please find the following table for details

Phenomenon	LED Alarm	Possible root cause	How to target the root cause	Solution
Battery is empty over discharged	LED is off	1) Off-grid installation-battery can't be charged for over 2 weeks due to no production of PV system(rainy season, snow season, or PV system fault).	Check the battery voltage through the reserved service port. If 10K LV is less than 40V, please turn off the battery and contact with Soluna.	Contact with Soluna for additional support and next steps.
		2) Customer didn't turn off the battery or over 2 weeks in the scenario such as: A. Installation is not finished. B. System failure, not running.	Check the battery voltage through the reserved service port. If 10K LV is less than 40V, please turn off the battery and contact with Soluna.	Contact with Soluna for additional support and next steps.
		3) The battery was stocked for over 2 years without charging.	Check the battery voltage through the reserved service port. If 10K LV is less than 40V, please turn off the battery and contact with Soluna.	Contact with Soluna for additional support and next steps.
Battery is not working correct in parallel installation	N/A	1) Battery communication cable is loose or not correct.	Check the communication cable status.	Re-plug or change the communication cable.
		2) Battery power cable is loose or not connected correctly.	Check the battery power cable.	Fasten the power cable .
		3) Battery communication port resistor missing or wrong dial	Check the resistor dialing.	Plug the communication port resistor or re-dial.
		4) Battery firmware is not the latest.	Please use canbus tool box or Soluna e cloud to check firmware reversion.	Update the firmware to the latest version.

12 Trouble shooting guideline

Please find the following table for details

Phenomenon	LED Alarm	Possible root cause	How to target the root cause	Solution
Battery wifi connecting failure	N/A	1) The Wifi network is not compatible	Check the end user network type.	Please choose only 2.4G wifi mode.
		2) Connecting fail	APP will remind.	Please read the SOP of wifi setting up.
		3) System establish failed due to S/N valid	APP will remind.	Contact with Soluna for additional support and next steps.
Minor Alarm message on Soluna monitoring system	N/A	1) Battery reach to 1st level alarm such as battery over voltage	No need further action.	Please ignore it, this alarm message is only used for inverter strategy. The power of charging/ discharging will be limited.
Moderate Alarm message on Soluna monitoring system	N/A	2) Battery reach to 2nd level alarm such as battery over voltage	No need further action.	Please ignore it, this alarm message is only used for inverter strategy. The power of charging/ discharging will be limited.
Protection Alarm message on Soluna monitoring system	LED is blinking or yellow	3) Battery reach to 3rd level alarm such as battery over voltage	1) Please check the inverter LCD/LED or APP for the battery alarm information. 2) Please check the Soluna e cloud for battery alarm information.	Battery will shut down, please contact with Soluna for additional support and next steps.

13 Depth of Discharge(DOD) Setting for Inverter

To ensure optimal performance and smooth operation of the battery, the following settings for the inverter:

On-Grid DOD: 80%

Off-Grid DOD: 70%

In energy storage systems, reducing the depth of discharge (DOD) of lithium batteries is aimed at improving system economics, extending battery life, enhancing safety, and optimizing performance. Below are the specific reasons:

1. Extending Battery Life

- The cycle life of lithium batteries is closely related to the depth of discharge. Deep discharge (e.g., 80%-100% DOD) accelerates battery aging, leading to faster capacity degradation.
- Reducing DOD (e.g., controlling it between 20%-80%) can significantly extend the battery's cycle life, thereby lowering long-term maintenance and replacement costs for the energy storage system.

2. Improving System Economics

- Batteries account for a significant portion of the cost in energy storage systems. Extending battery life means reducing the frequency of battery replacements and lowering the total lifecycle cost.
- Although reducing DOD decreases the available energy per cycle, the overall energy throughput (total charge-discharge capacity) may increase by extending battery life, there by improving economic efficiency.

3. Enhancing Safety

- Deep discharge increases the risk of over-discharge, causing the battery voltage to drop too low, which may lead to irreversible chemical damage (e.g., dissolution of the copper current collector in the anode).
- Reducing DOD can prevent over-discharge, minimize safety risks such as thermal runaway, and ensure stable operation of the energy storage system.

If you have any questions, feedback, or need assistance, please feel free to reach out to us.
We are here to help!

Soluna (Shanghai) Co.,Ltd

Add: No.3492 Jinqian Road, Shanghai, China 201406

Tel: +86-21-57475835

Email: sales@solunabattery.com

Web: www.solunabattery.com

Social media: <https://www.linkedin.com/company/solunabattery>